

## **CREWSAVER SERVICING AND MAINTENANCE BULLETIN No. 13**



**ISSUED TO:** All Approved Service Stations,  
All holders of Servicing Certificates and  
Care & Maintenance Certificates for all  
Crewsaver lifejackets.

**DATE:** January 2006

**SUBJECT:** Mouth Inflation Valve Caps

The mouth inflation valve cap which we fit to our lifejackets changed about six years ago from the 'stay put' type to the 'loose fit' type. Since that date both types of cap have remained in use in the field. We have now decided that, for the sake of consistency, all of the old style of caps should be replaced by the new 'loose fit' caps.

We recommend that this replacement should be done when the lifejackets undergo their annual service. The pictures overleaf show the two different types of cap. The older 'stay put' cap has a knurled dome in the centre which holds it in place in the tube. The 'loose fit' has a smaller, smooth dome.

Care should be taken when fitting the new cap to ensure that it is fitted the right way up. Supplies of the replacement caps, part number 10151, can be ordered through our Sales Department.

Norman Kitching  
Crewsaver  
QA Manager

**CREWSAVER**  
MUMBY ROAD, GOSPORT, HANTS. PO12 1AQ, ENGLAND.  
TEL: +44 (0) 23 9252 8621 FAX: +44 (0) 23 9251 0905  
email: [sales@crewsaver.co.uk](mailto:sales@crewsaver.co.uk)  
A COSALT:plc Company



**OLDER 'STAY PUT'  
STYLE OF CAP**



**CURRENT  
'LOOSE FIT'  
STYLE OF CAP**